# REDIEN "



### Before operation

Annex on limited length

Flat and mane shaving Advantage 3 limit combs (1mm,2mm,3mm)

Decide the length of the haircut










- Select proper limit comb according to the length of haircut
- Remove the limit comb

- A. Clockwise rotation of limit comb
- B. Pull it off the blade










- Charging instructions
- This machine uses 5V 600mA lithium battery with USB cable, which is powerful. The indicator light is on when the power is turned on, and the indicator light flashes when the power is less than 10% to indicate charging. The shaver is charged for 2 hours. When USB is charged, the indicator light flashes for charging. When the shaver is fully charged, the indicator light is always on to indicate that it is fully charged.










## Parameter

| Product Name | professional hairdresser              |
|--------------|---------------------------------------|
|              | RN-8150                               |
| Battery      | Specification: lithium battery 600mAh |
|              | Charging time: 2 hours                |
| Charger      | Voltage: 100-240V, 50 / 60Hz          |
|              | Output: DC5V 1000mA                   |
|              | Power: 5W                             |
| Use time     | About 85 minutes.                     |

## Before use

#### PART NAME



#### **PARTS**





## Marning

| Do not touch with<br>wet hands     | Do not use wet hands to unplug the charger to avoid electric shock.   | EX. |
|------------------------------------|---|-----|
| Sprinkling threat                  | Please do not use it in the bathroom to avoid electric shock.   | 4   |
| Do not disassemble                 | Please do not improve, decompose or repair the product at will. Danger of fire, electric shock or injury.           |     |
| Do not use in humid<br>environment | Do not use water to clean the fuselage. It is easy to cause electric shock or short circuit.                        |     |
| Charge                             | Please do not use it when the voltage is higher than 220V. May cause electric shock or fire.                        | 際   |
| Prohibit                           | Please do not damage the wires. Do not machine, bend, stretch or twist. It is easy to cause electric shock or fire. |     |
|                                    | It should be replaced by the designated service department for safety.  | b   |
| When the battery life is exhausted | Take it out to the designated recycling pla   | *   |

Suggestion: generally, the shaver can be used for about 85 minutes after charging, but we suggest that when you use it for about 70 minutes or when you think the power of the shaver drops and the indicator light keeps flashing, you can charge the shaver and then use it again. Do not wait for the power to run out before charging. This operation is conducive to prolonging the life of the shaver.